



SYNERGY TELECOM PVT LTD

Cotran Rubber Mastic Tape/Butyle Tape Part No. KC80



Dimension

Widht	-	51mm
Thickness	-	1.65mm
Length	-	3M

INSTALLATION INSTRUCTIONS



Picture 1

RF CONNECTOR: Make sure that the connector and coaxial cable are clean and dry before application.



Picture 2

Use **BRIPOL SEALANT** in TAPE form with removable release liner.



Picture 3

Peel **BRIPOL SEALANT** from release liner and start wrapping around the Connector diagonally and overlapping to half width with each wrap.



Picture 4

Continue wrapping beyond the jumper connector. Finish the application with last wrap straight (Not Diagonal).



Picture 5

Now Wrap the connector diagonally with 48mm / 19mm PVC Insulation Tape overlapping to half width and extend the wrapping beyond the previous wrapping of **BRIPOL SEALANT** Tape.

IMPORTANT TIPS

1. Don't stretch BRIPOL SEALANT Tape. Apply only enough tension to provide a tight and smooth wrap.
2. When wrapping overlap the tape to half width.
3. Don't pull the tape to tear it. Always cut it with Scissors only.
4. Press the tape against the connector body and cable with thumb and fingers to remove any gaps and to ensure that all the wraps fuse together to form one sheath around the connector.
5. Store **BRIPOL SEALANT TAPE** at temperature between - 25°C to 40°C, away from heat, water, moisture and direct Sun light.
6. Shelf Life of BRIPOL SEALANT is 12 months.