

Waveguide Tripod

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd



ergy Telecom (P) Ltd argy Telecom (P) Ltd ergy Telecom (P) Ltd ergy Telecom (P) Ltd ergy Telecom (P) Ltd ergy Telecom (P) Ltd

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

Model 5145 Tripod Stands are made to hold the antenna.

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

This is useful for plotting, the polar pattern of antenna.

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

It consists of a triangular steel base with leveling screws, on which three legs are connected to a block. A 0-360° round scale is provided to read the rotation of antenna. The height of antenna is adjustable Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd from 1 1 0 to 1 50 cms.

These are available for S, C, J, X, Ku, Kand R-bands. Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd

13-15 RPS flats, E-block, Vikaspuri, N Delhi-110018, India Phone-91 11 28533349, Mobile-91 98101 38894, Fax -91 11 2853 1435, E-mail: pradeep@rfconnectorhouse.com, Website: http://www.rfconnector.info/

Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd Synergy Telecom (P) Ltd