

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4897 TNC MALE CRIMP A)RG58/U B)RG59/U C)RG6/U D)174/U</p> 	<p>HL4904 N FEMALE CRIMP TYPE A)RG58/U B)RG59/U</p> 	<p>HL4911 N FEMALE BULKHEAD RECEPTACLE</p> 	<p>HL4918 N MALE TO TNC MALE</p> 
<p>HL4898 N MALE CRIMP TYPE A)RG58/U B)RG59/U</p> 	<p>HL4905 N female bulkhead crimp type A)RG58/U B)RG59/U</p> 	<p>HL4912 N MALE TO N MALE</p> 	<p>HL4919 N MALE TO TNC FEMALE</p> 
<p>HL4899 RIGHTANGLE N MALE CRIMP TYPE A)RG58/U B)RG59/U</p> 	<p>HL4906 N FEMALE PANEL RECEPTACLE A)RG58/U B)RG59/U</p> 	<p>HL4913 N MALE TO N FEMALE</p> 	<p>HL4920 N MALE TO UHF MALE</p> 
<p>HL4900 N MALE CLAMP TYPE A)RG58/U B)RG59/U</p> 	<p>HL4907 N FEMALE CLAMP TYPE A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4914 N FEMALE TO N FEMALE</p> 	<p>HL4921 N MALE TO UHF FEMALE</p> 
<p>HL4901 RIGHTANGLE N MALE CLAMP TYPE A)RG58/U B)RG59/U</p> 	<p>HL4908 N female bulkhead clamp type A)RG58/U B)RG59/U</p> 	<p>HL4915 N MALE TO BNC FEMALE</p> 	<p>HL4922 F FEMALE TO N FEMALE</p> 
<p>HL4902 N MALE SOLDER TYPE BULKHEAD</p> 	<p>HL4909 N FEMALE CLAMP PANEL RECEPTACLE A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4916 N MALE TO F FEMALE</p> 	<p>HL4923 N DOUBLE FEMALE CHASSIS</p> 
<p>HL4903 N MALE SOLDER PANEL</p> 	<p>HL4910 TNC FEMALE BULHEAD</p> 	<p>HL4917 N MALE TO RCA FEMALE</p> 	<p>HL4924 N FEMALE TO TNC FEMALE</p> 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4869 TNC FEMALE BULKHEAD CLAMP A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4876 RIGHTANGLE TNC MALE TO TNC FEMALE</p> 	<p>HL4883 TNC MALE TO N FEMALE</p> 	<p>HL4890 TNC MALE TO DOUBLE TNC MALE</p> 
<p>HL4870 TNC FEMALE PANEL CLAMP</p> 	<p>HL4877 TNC DOUBLE FEMALE</p> 	<p>HL4884 TNC MALE TO RCA MALE</p> 	<p>HL4891 TNC MALE TO DOUBLE TNC FEMALE</p> 
<p>HL4871 TNC FEMALE TWIST ON A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4878 TNC DOUBLE FEMALE BULKHEAD</p> 	<p>HL4885 TNC MALE TO RCA FEMALE</p> 	<p>HL4892 TNC FEMALE TO DOUBLE TNC MALE</p> 
<p>HL4872 TNC FEMALE BULKHEAD</p> 	<p>HL4879 TNC DOUBLE FEMALE PANEL</p> 	<p>HL4886 TNC MALE TO UHF FEMALE</p> 	<p>HL4893 THREE TNC FEMALE</p> 
<p>HL4873 TNC FEMALE CHASSIS</p> 	<p>HL4880 TNC MALE TO UHF MALE</p> 	<p>HL4887 TNC FEMALE TO RCA MALE</p> 	<p>HL4894 TNC MALE MOLD & CRIMP A)RG58/U B)RG59/U C)RG6/U D)RG174/U</p> 
<p>HL4874 TNC MALE TO TNC MALE</p> 	<p>HL4881 TNC MALE TO BNC FEMALE</p> 	<p>HL4888 TNC FEMALE TO RCA FEMALE</p> 	<p>HL4895 TNC MALE ANTENNA MOUNT</p> 
<p>HL4875 TNC MALE TO TNC FEMALE</p> 	<p>HL4882 N MALE TO F FEMALE</p> 	<p>HL4889 TNC FEMALE TO UHF FEMALE</p> 	<p>HL4896 RIGHTANGLE TNC MALE TO TNC FEMALE</p> 

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4841 MINI UHF DOUBLE MALE</p> 	<p>HL4848 MINI UHF FEMALE TO N MALE</p> 	<p>HL4855 MINI UHF MALE TWIST ON A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4862 Right angle tnc male twist on A)RG58/U B)RG59/U C)RG6/U</p> 
<p>HL4842 MINI UHF DOUBLE FEMALE</p> 	<p>HL4849 MINI UHF FEMALE TO TNC MALE</p> 	<p>HL4856 UHF FEMALE TO RCA MALE</p> 	<p>HL4863 TNC MALE CHASSIS MOUNT</p> 
<p>HL4843 MINI UHF MALE TO BNC FEMALE</p> 	<p>HL4850 MINI UHF FEMALE TO UHF MALE</p> 	<p>HL4857 TNC MALE PANEL CRIMP A)RG58/U B)RG59/U C)RG6/U D)174/U</p> 	<p>HL4864 TNC MALE BULKHEAD</p> 
<p>HL4844 MINI UHF MALE TO N FEMALE</p> 	<p>HL4851 RIGHTANGLE MINI UHF MALE TO UHF FEMALE</p> 	<p>HL4858 TNC right angle male, crimp type A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4865 TNC FEMALE CRIMP TYPE A)RG58/U B)RG59/U C)RG6/U D)174/U</p> 
<p>HL4845 MINI UHF MALE TO TNC FEMALE</p> 	<p>HL4852 RIGHTANGLE MINI UHF MALE TO BNC FEMALE</p> 	<p>HL4859 TNC MALE , CLAMP TYPE A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4866 TNC FEMALE PANEL CRIMP A)RG58/U B)RG59/U C)RG6/U D)174/U</p> 
<p>HL4846 MINI UHF MALE TO UHF FEMALE</p> 	<p>HL4853 MINI UHF MALE TO UHF DOUBLE FEMALE</p> 	<p>HL4860 RIGHTANGLE TNC MALE CLAMP A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4867 TNC FEMALE BULKHEAD CRIMP A)RG58/U B)RG59/U C)RG6/U</p> 
<p>HL4847 MINI UHF FEMALE TO BNC MALE</p> 	<p>HL4854 MINI UHF THREE FEMALE</p> 	<p>HL4861 TNC MALE TWIST ON A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4868 TNC FEMALE CLAMP A)RG58/U B)RG59/U C)RG6/U</p> 

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4813 BNC MALE TO DOUBLE BNC FEMALE</p> 	<p>HL4820 UHF Connector with reducer (SILVER PLATED)</p> 	<p>HL4827 UHF FEMALE SOLDER PANEL RECEPTACLE</p> 	<p>HL4834 UHF MALE TO TNC FEMALE</p> 
<p>HL4814 BNC MALE TO DOUBLE FEMALE</p> 	<p>HL4821 UHF MALE</p> 	<p>HL4828 UHF FEMALE BULKHEAD</p> 	<p>HL4835 UHF FEMALE TO 3.5MM MONO PLUG</p> 
<p>HL4815 BNC THREE FEMALE</p> 	<p>HL4822 UHF DOUBLE MALE</p> 	<p>HL4829 RIGHTANGLE UHF FEMALE TWIST ON</p> 	<p>HL4836 RIGHTANGLE UHF MALE TO FEMALE</p> 
<p>HL4816 BNC FOUR FEMALE</p> 	<p>HL4823 UHF DOUBLE FEMALE</p> 	<p>HL4830 UHF DOUBLE FEMALE BULKHEAD</p> 	<p>HL4837 UHF MALE TO DOUBLE UHF FEMALE</p> 
<p>HL4817 BNC THREE FEMALE TO BNC MALE</p> 	<p>HL4824 UHF MALE TO BNC FEMALE</p> 	<p>HL4831 UHF MALE TO F FEMALE</p> 	<p>HL4838 UHF THREE FEMALE</p> 
<p>HL4818 UHF MALE CRIMP TYPE A) RG 58/U B) RG 59/U</p> 	<p>HL4825 REDUCER USED WITH TDB-5506 A)RG58/U B)RG59/U</p> 	<p>HL4832 UHF MALE TO N FEMALE</p> 	<p>HL4839 MINI UHF FEMALE CRIMP TYPE A) RG58/U B) RG59/U C) RG6/U</p> 
<p>HL4819 UHF MALE MOLDED CRIMP TYPE A) RG 58/U B) RG 59/U</p> 	<p>HL4826 RIGHTANGLE UHF MALE TWIST ON A)RG58/U B)RG59/U C)RG213/U</p> 	<p>HL4833 UHF MALE TO RCA FEMALE</p> 	<p>HL4840 MINI UHF FEMALE CRIMP TYPE A) RG58/U B) RG59/U C) RG6/U</p> 

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4785 BNC MALE TO N FEMALE</p> 	<p>HL4792 BNC male right angle clamp A) RG58/U B) RG59/U C) RG6/U</p> 	<p>HL4799 BNC MALE MOLDED & CRIMP A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4806 BNC FEMALE TO 3.5MM MONO POUG MALE</p> 
<p>HL4786 BNC FEMALE TO N FEMALE</p> 	<p>HL4793 BNC MALE ANTENNA MOUNT</p> 	<p>HL4800 BNC MALE RIGHT ANGLE TO BNC FEMALE</p> 	<p>HL4807 BNC FEMALE MOLDED</p> 
<p>HL4787 BNC FEMALE PANEL CLAMP A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4794 RIGHT ANGLE BNC MALE TO TNC FEMALE</p> 	<p>HL4801 BNC MALE TO BNC FEMALE</p> 	<p>HL4808 BNC FEMALE P.C.B. MOUNT</p> 
<p>HL4788 BNC MALE TO RCA FEMALE</p> 	<p>HL4795 BNC MALE CRIMP LOCK TYPE</p> 	<p>HL4802 BNC FEMALE RIGHT ANGLE CHASSIS MOUNT</p> 	<p>HL4809 BNC THREE MALE</p> 
<p>HL4789 BNC FEMALE TO RCA FEMALE</p> 	<p>HL4796 BNC MALE TO TNC MALE</p> 	<p>HL4803 BNC MALE RIGHT ANGLE CHASSIS MOUNT</p> 	<p>HL4810 BNC MALE TO DOUBLE BNC FEMALE</p> 
<p>HL4790 BNC Terminator protective cap A)50 OHM B)75 OHM C)90 OHM</p> 	<p>HL4797 BNC MALE TO UHF MALE</p> 	<p>HL4804 BNC FEMALE BULKHEAD CLIMP TYPE A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4811 BNC THREE FEMALE</p> 
<p>HL4791 BNC female right anale twiston A)50 OHM B)75 OHM C)90 OHM</p> 	<p>HL4798 BNC MALE TO N MALE</p> 	<p>HL4805 BNC female to BNC female (long thread) A) W/washer+nut+rubber B) W/washer+nut</p> 	<p>HL4812 BNC FEMALE TO DOUBLE MALE</p> 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4757 BNC MALETWIST-ON A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4764 BNC FEMALE CHASSIS MOUNT</p> 	<p>HL4771 BNC MALE TO F MALE</p> 	<p>HL4778 BNC FEMALE TERMINATOR A)50 OHM B)75 OHM C)90 OHM</p> 
<p>HL4758 BNC FEMALE TWIST ON A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4765 BNC MALE CLAMP PANEL A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4772 BNC FEMALE TO F MALE</p> 	<p>HL4779 DOUBLE BNC MALE</p> 
<p>HL4759 BNC MALE CLAMP A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4766 BNC FEMALE CRIMP PANEL A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4773 BNC MALE TO PAL FEMALE</p> 	<p>HL4780 DOUBLE BNC FEMALE</p> 
<p>HL4760 BNC FEMALE CLAMP A)RG58/U B)RG59/U C)RG6/U</p> 	<p>HL4767 BNC MALE TO F FEMALE</p> 	<p>HL4774 BNC FEMALE TO F QUICK MALE</p> 	<p>HL4781 BNC MALE TO TNC FEMALE</p> 
<p>HL4761 BNC Male bulkhead long thread A)RG58/U B)RG59/U</p> 	<p>HL4768 BNC FEMALE TO F FEMALE</p> 	<p>HL4775 BNC MALE TO PAL MALE</p> 	<p>HL4782 BNC FEMALE TO TNC FEMALE</p> 
<p>HL4762 BNC FEMALE BULKHEAD LONG THREAD A) With washer+nut B) W/o washer+nut</p> 	<p>HL4769 BNC MALE TO RCA MALE</p> 	<p>HL4776 BNC FEMALE TO PAL MALE</p> 	<p>HL4783 BNC MALE TO UHF FEMALE</p> 
<p>HL4763 BNC MALE CHASSIS MOUNT</p> 	<p>HL4770 BNC FEMALE TO RCA MALE</p> 	<p>HL4777 BNC MALE TERMINATOR A)50 OHM B)75 OHM C)90 OHM</p> 	<p>HL4784 BNC FEMALE TO UHF FEMALE</p> 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4729 PAL FEMALE (BULKHEAD)</p> 	<p>HL4736 RIGHTANGLE F MALE TO F FEMALE</p> 	<p>HL4743 F DOUBLE FEMALE USED BY QUICKCONNECTION</p> 	<p>HL4750 F FEMALE TO TNC FEMALE</p> 
<p>HL4730 F MALE TO F MALE</p> 	<p>HL4737 RIGHTANGLE F QUICK MALE TO F FEMALE</p> 	<p>HL4744 F MALE TO TNC MALE</p> 	<p>HL4751 F FEMALE TO N FEMALE</p> 
<p>HL4731 F MALE TO PAL MALE</p> 	<p>HL4738 F THREE FEMALE</p> 	<p>HL4745 F MALE TO N MALE</p> 	<p>HL4752 F FEMALE TO UHF FEMALE</p> 
<p>HL4732 F MALE TO PAL FEMALE</p> 	<p>HL4739 F quick male to Double F female</p> 	<p>HL4746 F MALE TO UHF MALE</p> 	<p>HL4753 BNC MALE CRIMP A)RG58/U B)RG59/U C)RG6/U D)RG174/U</p> 
<p>HL4733 F MALE TO RCA MALE</p> 	<p>HL4740 F MALE TO TWO FEMALE</p> 	<p>HL4747 F MALE TO TNC FEMALE</p> 	<p>HL4754 BNC FEMALE CRIMP A)RG58/U B)RG59/U C)RG6/U D)RG174/U</p> 
<p>HL4734 F QUICK MALE TO RCA FEMALE</p> 	<p>HL4741 F FOUR FEMALE</p> 	<p>HL4748 F MALE TO N FEMALE</p> 	<p>HL4755 BNC MALE,QUICK CRIMP A)RG58/U B)RG59/U C)RG6/U D)RG174/U</p> 
<p>HL4735 F FEMALE TO 3.5mm MONO PLUG</p> 	<p>HL4742 F MALE TO THREE FEMALE</p> 	<p>HL4749 F MALE TO UHF FEMALE</p> 	<p>HL4756 BNC FEMALE CRIMP TYPE A)RG58/U B)RG59/U C)RG6/U</p> 





















Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>HL4701 F CONNECTOR WITH RING A) RG58/U B) RG59/U C) RG6/U D) 7C2V</p> 	<p>HL4708 F quick molded</p> 	<p>HL4715 RIGHTANGLE F FEMALE PC MOUNT</p> 	<p>HL4722 F FEMALE TO RCA FEMALE</p> 
<p>HL4702 F WITH ATTACHED CRIMP RING</p> 	<p>HL4709 F male terminator (dummy load) A) 50 OHM B) 75 OHM C) 90 OHM</p> 	<p>HL4716 F FEMALE</p> 	<p>HL4723 F QUICK MALE TO F FEMALE</p> 
<p>HL4703 F CONNECTOR</p> 	<p>HL4710 F female bulkhead</p> 	<p>HL4717 F DOUBLE FEMALE A) W/ WASHER & NUTS B) W/O WASHER & NUTS</p> 	<p>HL4724 PAL MALE TO RCA FEMALE</p> 
<p>HL4704 F CONNECTOR</p> 	<p>HL4711 F female pc mount</p> 	<p>HL4718 PAL MALE TO F FEMALE</p> 	<p>HL4725 PAL FEMALE TO RCA FEMALE</p> 
<p>HL4705 F CONNECTOR WITH RING</p> 	<p>HL4712 F female bulkhead A) With washer & nuts B) W/o washer & nuts</p> 	<p>HL4719 PAL FEMALE TO F FEMALE</p> 	<p>HL4726 PAL MALE TO RCA FEMALE (BULKHEAD)</p> 
<p>HL4706 F MALE TWIST ON A) RG58/U B) RG59/U C) RG6/U D) 7C2V</p> 	<p>HL4713 F female bulkhead A) With washer & nuts B) W/o washer & nuts</p> 	<p>HL4720 PAL QUICK FEMALE TO F FEMALE</p> 	<p>HL4727 PAL QUICK MALE TO RCA FEMALE (BULKHEAD)</p> 
<p>HL4707 F MALE TWIST ON A) RG58/U B) RG59/U C) RG6/U D) 7C2V</p> 	<p>HL4714 F female bulkhead A) with washer & nuts B) w/o washer & nuts</p> 	<p>HL4721 RCA MALE TO F FEMALE</p> 	<p>HL4728 PAL MALE (BULKHEAD)</p> 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>SMA-KYY-3</p> 	<p>SMA-JYY12 L:23.3 SMA-JYY-4 L:19.8</p> 	<p>SMA-50KY-1</p> 	
<p>SMA-KYY24</p> 	<p>SMA-JYY L:18.1 SMA-JYY-9 L:16.5 SMA-JYY-5 L:17.5</p> 	<p>SMA-50KY-1-1</p> 	
<p>SMA-KYY-1</p> 	<p>SMA-JYY-1</p> 	<p>SMA-KYY40</p> 	
<p>SMA-KYY L:14.5 SMA-KYY-5 L:13.9 SMA-KYY-9 L:14.9</p> 	<p>SMA-JYY-3-2.5</p> 	<p>SMA-KYD2</p> 	
<p>SMA-JYY1 L:17.8 SMA-JYY2 L:18.6 SMA-JYY3 L:20.2 SMA-JYY4 L:19.4</p> 	<p>SMA-50KF</p> 	<p>HL5055 SMA-KE1 3.94jÅ0.25 SMA-KE2 3.18jÅ0.25 SMA-KE3 2.36jÅ0.25</p> 	
<p>HL5042 SMA-JYY6</p> 	<p>HL5049 SMA-50KF-1</p> 	<p>HL5056 YY 3564-KWE1 3.94jÅ0.25 YY 3564-KWE2 3.18jÅ0.25 YY 3564-KWE3 2.36jÅ0.25</p> 	
<p>HL5043 SMA-JYY7 L:18.6 SMA-JYY8 L:19.4</p> 	<p>HL5050 SMA-50KY</p> 		

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

BNC RG59/RG6 	F male compression connector waterproof 	SMA-50JK 	SMA-KYY3 L:27.4 SMA-KYY21 L:15.5 
BNC FEMALE TWLST ON RG6 	F male connector 	SMA-50KKF 	SMA-KYY6 L:20.5 SMA-KYY22 L:27.4 SMA-KYY-10 L:15.5 SMA-KYY-4 L:16.5 
RCA plug RG6 blue green black,red,yellow,white 	F male connector with blue colloidal ring 	SMA-G-JK (DETECTION HEAD) 	SMA-KYY10 L:15.3 SMA-KYY12 L:16.1 SMA-KYY-12 L:14.7 
RCA JACK RG6 BLUE GREEN BLACK,RED,YELLOW,WHITE 		SMA-50KKY-1 	SMA-KYY8 
RIGHTANGLE RCA PLUG RG6 	SMA-J2 SMA-75J2 SMA-J3 SMA-75J3 SMA-J4 SMA-75J4 SMA-J5 SMA-J12 	SMA-50JJW 	SMA-KYY23 
FCONNECTOR RG6 QUAD SHIELD 	SMA-JW2 SMA-75JEW2 SMA-JW3 SMA-75JEW3 SMA-JW4 SMA-75JW4 SMA-JW5 SMA-JW12 	SMA-50KKW 	SMA-KYY-11 
F male connector 	SMA-K2 SMA-75K2 SMA-K3 SMA-75K3 SMA-K4 SMA-75K4 SMA-K5 SMA-K12 	SMA-KYY1 L:12 SMA-KYY2 L:17.5 	SMA-KYY-13 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

<p>RIGHTANGLE RCA PLUG</p> 	<p>RCA DOUBLE FEMALE</p> 	<p>F DOUBLE FEMALE</p> 	<p>F CONNECTOR WITH YELLOW COLLOIDAL COVER</p> 
<p>RIGHTANGLE UHF MALE</p> 	<p>FME FEMALE CRIMP A) RG58/U B) RG59/U C) RG174/U</p> 	<p>F MALE WITH PRING</p> 	<p>F CONNECTOR WITH INSULATOR & PIN</p> 
<p>BNC PLUG WITH METAL HANDLE W/SPING</p> 	<p>F FEMALE WITH BLACK PLASTIC A: WITH WASHER & NUT B: WITHOUT WASHER & NUT</p> 	<p>F MALE TO F MALE</p> 	<p>F CONNECTOR WITH BLUE COLLOIDAL COVER</p> 
<p>RIGHTANGLE METAL PAL PLUG</p> 	<p>F DOUBLE FEMALE</p> 	<p>F MALE TO F FEMALE (A) 6dB (B) 10dB</p> 	<p>FME DOUBLE FEMALE</p> 
<p>RIGHTANGLE METAL PAL JACK</p> 	<p>F MALE TIN</p> 	<p>F DOUBLE FEMALE USED BY QUICK CONNECTION</p> 	<p>RIGHT ANGLE PAL MALE TO F FEMALE</p> 
<p>FME DOUBLE FEMALE</p> 	<p>F MALE ATTACHED RING FR CATV+O RING (B) RG-59U (C) RG-6U (SC)+DILICON</p> 	<p>F CONNECTOR WITH BLACK COLLOIDAL COVER</p> 	<p>F FEMALE TO PIN TYPE CONNECTOR</p> 
<p>FME MALE CRIMP A: RG59/U B: RG6/U</p> 	<p>F FEMALE</p> 	<p>F CONNECTOR WITH BALCK COLLOIDAL COVER</p> 	<p>Locking terminator coppery</p> 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

SMA MALE TO UHF FEMALE 	SMA FEMALE TO TNC MALE 	BNC MALE SOLDERLESS 	UHF MALE SOLDERLESS 
SMA FEMALE TO BNC MALE 	SMA FEMALE TO TNC FEMALE 	BNC FEMALE SOLDERLESS 	RIGHTANGLE BNC MALE 
SMA FEMALE TO BNC FEMALE 	SMA FEMALE TO UHF MALE 	F MALE SOLDERLESS 	RIGHTANGLE BNC FEMALE 
SMA FEMALE TO MINI UHF MALE 	SMA FEMALE TO UHF MALE 	F QUICK MALE SOLDERLESS 	RIGHTANGLE F MALE 
SMA female to mini uhf female 	RIGHTANGLE SMA MALE TO SMA FEMALE 	PAL MALE SOLDERLESS 	RIGHTANGLE F QUICK MALE 
SMA FEMALE TO N MALE 	SMA male to double SMA female 	PAL FEMALE SOLDERLESS 	RIGHTANGLE PAL MALE 
SMA FEMALE TO N FEMALE 	SMA three female 	RCA PLUG SOLDERLESS 	RIGHTANGLE PAL FEMALE 

Synergy Telecom P Ltd.

F/BNC/UHF/TNC/N/SMA/SMB Series

N FEMALE TO UHF FEMALE 	N THREE MALE 	SMA FEMALE BULKHEAD 	SMA MALE TO MINI UHF MALE 
RIGHTANGLE N DOUBLE MALE 	N MALE TERMINATOR A) 50OHM B) 75OHM C) 93OHM 	SMA FEMALE CHASSIS MOUNT 	SMA MALE TO MINI UHF FEMALE 
RIGHTANGLE N MALE TO N FEMALE 	N FEMALE TERMINATOR A) 50OHM B) 75OHM C) 93OHM 	SMA DOUBLE MALE 	SMA MALE TO N MALE 
RIGHTANGLE N DOUBLE FEMALE 	SMA MALE CRIMP TYPE 	SMA DOUBLE FEMALE 	SMA MALE TO N FEMALE 
N MALE TO DOUBLE N FEMALE 	RIGHTANGLE SMA MALE CRIMP TYPE 	SMA DOUBLE FEMALE BULKHEAD 	SMA MALE TO TNC MALE 
N THREE FEMALE 	SMA MALE BULKHEAD 	SMA MALE TO BNC MALE 	SMA MALE TO TNC FEMALE 
N FEMALE TO DOUBLE N MALE 	SMA MALE CHASSIS MOUNT 	SMA MALE TO BNC FEMALE 	SMA MALE TO UHF MALE 