

GARMIN GPSMAP-420/420s

Waypoints: 1500

Track log: 10,000 points, 20 saved tracks

Routes: 20

Memory: External memory card

Display type: QVGA display

Depth: 2500 feet

Waterproof: yes (IPX7)

Needs 12V battery to work

